

# WESTERFIELD MODELS, LLC.

## KIT TRUCK REFERENCE LIST

THIS IS THE WESTERFIELD MODELS TRUCK REFERENCE LIST. THIS LIST COVERS THE KNOWN TRUCKS THAT ARE APPROPRIATE FOR OUR KITS. WE HAVE TRIED TO LIST BOTH METAL AND PLASTIC TRUCKS AS RICHARD HENDRICKSON POINTED OUT THAT NEWER PLASTIC TRUCKS HAVE MUCH MORE DETAIL.. WE HAVE LISTED TAHOE MODEL WORKS TRUCKS AND KADEE TRUCKS FOR THE KITS WHERE THEY CAN BE USED.

PLEASE SEE OUR WEBSITE: [westerfieldmodels.com](http://westerfieldmodels.com) FOR A COMPLETE LISTING OF TAHOE TRUCKS AND KADEE TRUCKS/COUPLERS THAT ARE AVAILABLE FOR ORDERING WITH YOUR KITS.

SEE OUR SECURE MODEL STORE SECTION "ADD-ON TRUCKS & COUPLERS FOR KITS" TO ORDER KADEE TRUCKS AND/OR COUPLERS. PLEASE NOTE THAT KADEE PRODUCTS ARE ONLY AVAILABLE WITH A KIT PURCHASE AND NOT SOLD ALONE. NOTE THAT ON THIS LIST, KADEE 500 SERIES TRUCKS ARE LISTED. WE ALSO SELL KADEE 550,560 AND 1560 SERIES TRUCKS. PLEASE SEE THE KADEE WEBSITE FOR THE DIFFERENCES.

SEE OUR SECURE MODEL STORE SECTION "ADD-ON TRUCKS & COUPLERS FOR KITS" OR "TAHOE MODEL TRUCKS" TO ORDER TAHOE TRUCKS. TAHOE TRUCKS MAY BE ORDERED WITH A KIT AT A REDUCED PRICE OR ALONE. PLEASE ALSO SEE THE TAHOE TRUCKS SECTION FOR VOLUME PRICES.

IF YOU USE PLASTIC TRUCKS, YOU MAY NEED TO ADD EXTRA WEIGHT TO YOUR KIT.

IF YOU SEE ANY TRUCK LISTING THAT NEEDS TO BE CORRECTED OR HAVE AN ADDITIONAL TRUCK THAT WE SHOULD LIST, PLEASE SEND US AN EMAIL AT [westerfieldmodels@gmail.com](mailto:westerfieldmodels@gmail.com).

**1100 Series Operating Era: 1914-1953**  
**5800 Series Operating Era: 1922-1956**  
**5900 Series Operating Era: 1934-1964**  
#1100/5800/5900 \*\*\*DISCONTINUED KIT\*\*\*

**A-50-4/A-50-6/B-50-20:**  
Original - Vulcan Trucks: **Kadee #515 (M)**  
Modernized - Bettendorf: **Kadee #500(M)**

**A-50-6/A-50-6/B-50-20:**  
Original - T Section Trucks: **Bethlehem #1204**  
Or **Kadee #511 (M)**  
Modernized - Bettendorf: **Kadee #500 (M)**  
Later B-50-20: **TMW-209**

**1200 Series Operating Era: 1915-1975**  
#1200 \*\*\*DISCONTINUED KIT\*\*\*

**G22:**  
Crown Sideframe 70 T Trucks: **Wiseman #OT-5302**

**G22A:**  
Crown Sideframe 70 T Trucks: **Wiseman #OT-5302**

**G22B:**  
2F-F2, 2F-F4, or 2F-F5 100 Ton Coil-Elliptical Trucks: **Not Available**  
Sustitute: **Walthers #933-1012** or the **Bettendorf** of your choice and **PSC #31968 Leaf Springs**, Or **TMW-208**

**1300 Series Operating Era: 1902-1942**  
**2700 Series Operating Era: 1904-1934**  
**3500 Series Operating Era: 1929-1973**  
**5500 Series Operating Era: 1906-1942**  
#1300/2700/3500/5500

**Original XL:**  
Arch Bar Trucks : **TMW-203 or Kadee #501 (M)**

**Modernized XL:**  
Bettendorf or 2D-F8 Trucks: **Kadee #500 or #517 (M)**

**1400 Series Operating Era: 1910-1958**  
#1400/4000

**Bx.W:**

Andrews 538 Trucks: **TMW-212** or **Kadee #509 with Modifications**

**Bx.X/Y/Z:**  
Andrews 545 L Section Trucks:  
**Kadee #509 with Modifications**

**Bx.15/16/17:**  
Arch Bar Trucks: **TMW-203** or **Kadee #501**

**1500 Series Operating Era: 1909-1975**  
#1500

**As Built :**  
Arch Bar Trucks: **TMW-203** or **Kadee #501 (M)**

**Modernized:**  
Arch Bar or Bettendorf: **TWM-211** or **Kadee #501/#500 (M)**

**1600 Series Operating Era: 1910-1952**  
#1600

**Original TY:**  
Not Made, These will work: **Bethlehem #1212**

**Original TCC:**  
Not Made, These will work: **Bethlehem #1227**

**Modernized versions:**  
Bettendorf: **Kadee #500 (M)**

**1700 /1800 Series Operating Era: 1904-1953**  
#1700/1800 \*\*\* SOME 1800's DISCONTINUED\*\*\*

**As Built :** Arch Bar Trucks: **TMW-203** or **Kadee #501**

**Rebuilt/ Modern Cars:**  
Andrews: **TMW-212** or **Kadee #509 (M)**

Bettendorf: **Kadee #500 (M)**

**1900 /2000Series Operating Era: 1925-1973**  
#1900/2000

**Buckeye ARA Trucks: TMW-206**

**2100 Series Operating Era: 1923-1965**  
#2100 \*\*\* SOME 2100's DISCONTINUED\*\*\*

**Original Cars:**  
USRA 70 Ton Trucks: **Kitbash MDC#2918 Trucks**

**Peaked End Cars:**  
Andrew Trucks: **TMW-212** or **Bethlehem #1227**

**2200 Series Operating Era: 1903-1960**  
#2200

**Arch Bar Trucks:**  
**TMW-203** or **Kadee #501 (M)**

**2300 Series Operating Era: 1900-1961**  
**2400 Series Operating Era: 1904-1950**  
#2300/2400

**GL/GLc as Built :**  
Arch Bar Trucks: **TMW-203** or **Kadee #501 (M)**

**GLc/GLca Modern :**  
PRR 2DF8 Trucks: **Kadee #517 (M)**

**Early GL, PSC :**  
Diamond Arch Bar: **Wiseman #OT-5301**

**PSC Modern:**  
Bettendorf : **Kadee #500 (M)**

**2500 Series Operating Era: 1922-1956**  
#2500

Bettendorf Trucks: **Kadee #500 (M)**

**2600 /6000 Series Operating Era: 1911-1973**  
**6500 /6600/6700 Series Operating Era: 1922-1975**  
#2600/6000/6500/6600/6700

**Delivered, 1911-1913:**  
Arch Bar Trucks: **TMW-203** or **Bethlehem #1207 (M)**

**42' 1915 Cars :**  
Vulcan Trucks : **Bethlehem #1220 (M)**

**All other Cars :** NWX Cars: **TMW-214**  
URTX Cars: **TMW-206** Or  
Bettendorf: **Kadee #500 (M)**

**2800 Series Operating Era: 1925-1973**  
#2800

**As Built to Early 1930's:**  
Arch Bar Trucks: **TMW-203** or **Bethlehem #1207 (M)**

**Modern Cars :** Bettendorf Trucks: **Kadee #500 (M)**

**2900/3000 Series Operating Era: 1921-1967**  
#2900/3000

**As Built, 1922-23 :**  
T Section Bettendorf: **Kadee #511 (M)**

**All Other Versions :**  
Bettendorf Trucks : **Kadee #500 (M)**

**3100 Series Operating Era: 1910-1970**  
**3200 Series Operating Era: 1922-1970**  
#3100/3200 \*\*\* DISCONTINUED KIT \*\*\*

**H21:**  
Arch Bar Trucks : **TMW-203** or **Kadee #501 (M)**

**H21A:**  
70 T Crown Cast Sideframe Trucks:  
**Wiseman #OT-5302**

**W-1, Early :**  
Bettendorf T Section Trucks:  
**Bethlehem #1204**  
OR : Andrews Trucks : **Bethlehem #1227**

**W-1, Late :**  
Bettendorf Trucks : **Kadee #500 (M)**

**3300 Series Operating Era: 1918-1970**  
**7200 Series Operating Era: 1920-1973**  
#3300/7200

**USRA SS Box Cars:**  
Andrews Trucks : **TMW-212** or **Bethlehem #1227** or **Kadee #509 (M)**

**CPR Cars:**  
Original: Arch Bar Trucks: **TMW-203** or **Kadee #501 (M)**  
Modern, 1930's: Bettendorf: **Kadee #500 (M)**

**3400 Series Operating Era: 1899-1970**  
#3400

**PSC Ore Cars:**  
PSC Diamond Arch Bar Trucks:  
**Wiseman #OT-5301**

**3600 Series Operating Era: 1923-1973**  
**3700 Series Operating Era: 1953-1973**  
**7600 Series Operating Era: 1943-1973**  
#3600/3700/7600

**As Built, Class 551:**  
Andrews U Section Trucks: **TMW-212**

**Modern:**  
Bettendorf: **Kadee #500 (M)**

**3800 Series Operating Era: 1918-1970**  
#3800

**USRA DS Box:**  
Andrews Trucks: **TMW-212** or **Bethlehem #1227**

**3900 Series Operating Era: 1894-1929**

#3900

**Original:**

5' W.B. Swing Motion Arch Bar Trucks:  
**Wiseman #OT5304**

**Modern:**

Arch Bar Trucks: **TMW-203** or  
**Kadee #501 (M)**

**4100 Series Operating Era: 1922-1970**  
#4100

**SU Box, Original:**

Arch Bar Trucks: **TMW-203** or  
**Kadee #501 (M)**

**SU Box, Modern:**

Bettendorf Trucks: **Kadee #500 (M)**

**4200/4300 Series Operating Era: 1914-1981**  
#4200/4300

**Fowler, Original:**

Arch Bar Trucks: **TMW-203** or **Kadee #501 (M)**  
Fowler, Original, Erie & Susquehanna:  
Andrews Trucks : **TMW-212** or  
**Bethlehem #1227**

**Fowler, Modern:**

Arch Bar Trucks: **TMW-203** or **Kadee #501 (M)**  
OR Bettendorf T Section Trucks: **Kadee #511 (M)**

**4400 Series Operating Era: 1914-1956**

#4400

**Fowler Box, Original:**

Vulcan Trucks: **Bethlehem #1220**

**Fowler Box, Modern:**

Andrews Trucks: **TMW-212** or  
**Bethlehem #1227**

**4500 Series Operating Era: 1907-1965**

#4500

**GRA, Original:**

Arch Bar Trucks: **TMW-203** or **Kadee #501 (M)**

**Modern:** Bettendorf Trucks: **Kadee #500 (M)**

**4600/4700/4800 Series Operating Era: 1929-1975**

#4600/4700/4800

**Bx-11/12/13:**

Dalman 1 Level Trucks: **Bethlehem #145**

Dalman 2 Level Trucks: (with Lateral Motion Detail):  
**TMW-202**

**4900 Series Operating Era: 1909-1956**

#4900

**R-30-4/5/6/11, As Built:**

Arch Bar Trucks: **TMW-203** or **Bethlehem #1207**

These trucks were retained until the car was rebuilt or  
scrapped in the 1930's.

**R-30-11, Rebuilt:**

Bettendorf T Section: **Bethlehem #1204** or  
**Kadee #511 (M)**

**5000/7700 Series Operating Era: 1910-1964**

#5000/7700

**M-15A:**

Type 8-M, Arch Bar Trucks: **TMW-203** or  
**Kadee #501 (M)**

**M-15B/C/D/E/F:**

Type 8-F, Diamond Arch Bar: **Wiseman #OT-5301**

**M-15A/H/J:**

Type 8-K/L, Andrews Trucks: **Tichy #3026/3012**

**M-15B/C/D/E/F, Modern:**

Bettendorf Trucks: **Kadee #500 (M)**

**M-15B/C/D/E/F, Type 8-B,**

Arch Bar Trucks: **Use Kadee #501,**  
**Modify with Kit Parts.**

**Express Cars:** Arch Bar Trucks with Leaf Springs:

**TMW-203** or **Kadee #501 With PSC #31968**

**Caboose Leaf Springs**

**5100 Series Operating Era: 1918-1951**

#5100

**HR Hopper:**

Pilcher (Lewis) Trucks: **Bethlehem #1241**

**5200 /5300/5400 Series Operating Era: 1905-1970**

#5200/5300/5400

**S-40-1/2 (SP):**

Arch Bar Trucks: **TMW-203** or **Kadee #501 (M)**

**S-40-3 (SP):**

Andrews Trucks: **TMW-212** or **Kadee #509 (M)**

**S-40-4 (UP):**

Andrews Trucks: **TMW-212** or **Kadee #509 (M)**  
or Vulcan Trucks: **Kadee #515 (M)**

**S-40-5 (UP):**

Vulcan Trucks: **Kadee #515 (M)**

**S-40-6 (UP):**

Vulcan Trucks: **Kadee #515 (M)**  
or Bettendorf T Section: **Kadee #511 (M)**

**S-40-8/9 (SP):**

Bettendorf T Section: **Kadee #511 (M)**

**S-40-10 (SP):**

Bettendorf T Section: **Kadee #511 (M)**

**5600 Series Operating Era: 1912-1952**

#5600

\*\*\* DISCONTINUED KIT \*\*\*

**Life of Cars:**

Bettendorf T Section: **Kadee #511 (M)**

**5700 Series Operating Era: 1898-1980**

#5700

**GLA, Original:**

Arch Bar Trucks: **TMW-203** or **Kadee #501 (M)**

**GLA, Modern:**

Bettendorf, 2D-F8 Trucks: **Kadee #517 (M)**

**6100 /6200 Series Operating Era: 1913-1953**

#6100/6200

**X25/X25A, Original:**

Crown 70 T Arch Bar Trucks: **Wiseman #OT5302**

**Modern:**

Bettendorf, 2D-F8 Trucks: **Kadee #517 (M)**

**6300 Series Operating Era: 1918-1965**

#6300/7000

**USRA Andrews Trucks:**

**FEC:** **TMW-212** or **Bethlehem #1227**

**ACL:** Original: Vulcan **Kadee #515**

Rebuilt: Bettendorf **Kadee #500**

**6400 Series Operating Era: 1913-1966**

#6400

**D&RGW:** Vulcan Trucks: **Kadee #515** or  
**Bethlehem #1220**

**Rock Island:**

Pre-1927: Bettendorf T Section:

**Bethlehem #1024** or **Kadee #511**

RI #133000 Series: Dalman 2 Level: **TMW-201**

**6800 /6900 Series Operating Era: 1920-1965**

#6800

**R-30-4/5/6/11/12/14:** Diamond Arch Bar:  
**Bethlehem #1207**

**R-30-11/14 & Most R-30-12/13 Cars:**

Bettendorf T Section: **Bethlehem #1204** or  
**Kadee #511**

**Early R-30-12/13:** Vulcan Trucks: **Kadee #515**

**Cars Rebuilt Late 1930's:** Bettendorf: **Kadee #500**

**R-40-2:** ARA Type Y Truck: **Kadee #517**

**7100 Series Operating Era: 1933-1990**

#7100

**Original:**

National Type B: **Eastern Car Works #9057**

Or: Dalman 1 Level Truck: **Bethlehem #145**

**Modern:** Bettendorf: **Kadee #500**

**7300 Series Operating Era: 1910-1956**

#7300

**Original:**

B-50-6: Bettendorf T Section: **Kadee #511**

B-50-9: Similar to Vulcan: **Kadee #515**

**Modern (1930's):** Bettendorf: **Kadee #500**

**7400 Series Operating Era: 1903-1952**

#7400

**Original:** Arch Bar Trucks: **TMW-203** or  
**Kadee #501**

**Mining RR's:** Pilcher Trucks: **Bethlehem #1215**

**7500 Series Operating Era: 1937-1975**

#7500

**Original:** Arch Bar Trucks: **TMW-203** or  
**Kadee #501**

**1930's XL Cars:** Bettendorf: **Kadee #500**

**1940's and Later:** 2d-F8 Trucks: **Kadee #517**

**7800 Series Operating Era: 1905-1957**

#7800

**Bx-O/5/14, All Versions:**

Andrews Class 538: **TMW-212** or

**Kadee #509 with Modifications**

Or

Andrews Class 545: **Kadee #509 with Modifications**

**7900 /10100 Series Operating Era: 1916-1964**

#7900/10100

**Original:** Bettendorf T Section: **Kadee #511**

**Modern:** Bettendorf: **Kadee #500**

**8000 Series Operating Era: 1926-1956**

#8000

**Original:** Arch Bar Trucks with Leaf Springs:  
**TMW-203** or **Kadee #501** with **PSC #31968**  
**Leaf Springs.**

**Late 1930's:** Bettendorf: **Kadee #500**

**8100 Series Operating Era: 1916-1975**

#8100

**Original:** Andrews: **TMW-212**

Or

70 Ton Crown Trucks: **Wiseman #OT-5302**

**Modern:** Bettendorf: **Kadee #500**

**8200 Series Operating Era: 1925-1970**

#8200

**Entire Life of Car:** 40 Ton ARA: **TMW-215**

**8300 Series Operating Era: 1929-1950**

#8300

**R-50-1:** Barber Lateral Motion: **TMW-209**

**8400 Series Operating Era: 1902-1937**

#8400

**Entire Life of Car:**

5' Wheelbase Arch Bar: **TMW-211**

**8500 Series Operating Era: 1905-1970**

#8500

Class 535 Arch Bar Trucks: TMW-203 or Kadee #501

Class 545/546/553 Andrews Trucks: TMW-212 or Bethlehem #1227

Type C Trucks: Bettendorf: Kadee #500

**8600 Series Operating Era: 1920-1950**

#8600

Rr-W/X: Class 545 Andrews: Kadee #509 with Modifications

Rr-Y/2/3: USRA Andrews Trucks: TMW-212

Rr-4: Bettendorf: Kadee #500

**8700 Series Operating Era: 1904-1937**

#8700

KF/KFA:

Original: Arch Bar Trucks: TMW-203 or Kadee #501

1930's: 2D-F8 Trucks: Kadee #517

**8800 Series Operating Era: 1926-1973**

#8800

Life of Car: Buckeye: TMW-206

**8900 Series Operating Era: 1911-1955**

#8900

XM-17/18:

Original: Arch Bar Trucks: TMW-203 or Kadee #501

Modern: Andrews Trucks: TMW-212 or Kadee #509

**10000 Series Operating Era: 1912-1965**

#10000

X23:

Original: Arch Bar Trucks: TMW-203 or Kadee #501

Modern: 2D-F8 Trucks: Kadee #517

**10200 Series Operating Era: 1923-1970**

#10200

U-5:

Original: Bettendorf T Section: Bethlehem #1204 or Kadee #511

Modern: Bettendorf U Section: Bethlehem #1205 or Kadee #500

**10300 Series Operating Era: 1937-1954**

#10300

B-50-6 Caboose:

Bettendorf T Section: Kadee #511

Or

Vulcan Trucks: Kadee #515

**10400 Series Operating Era: 1901-1961**

#10400

Original: Arch Bar Trucks: TMW-203 or Kadee #501

Modern: Bettendorf T Section: Kadee #511

1937 and Later: Bettendorf: Kadee #500

**10500/11100 Series Operating Era: 1902-1948**

#10500/11100

Original: 5'-6" Fox Style Trucks: Use Kit Castings, Wheelsets of your choice and Tichy Nylon Bearings.

Or

MDC/Athearn #2904/2924 Fox Trucks

Or

Bethlehem #1223

Cars with Arch Bar Trucks: TMW-203 or Kadee #501

After 1938: Bettendorf: Kadee #500

**10600 Series Operating Era: 1901-1952**

#10600

Life of Car: Arch Bar Trucks: TMW-203 or Kadee #501

**10700 Series Operating Era: 1921-1962**

#10700

Original: 1921: Bettendorf T Section: Kadee #511

Original: 1923: Vulcan: Kadee #515

Modern: Bettendorf: Kadee #500

**10800 Series Operating Era: 1909-1950**

#10800

Rr-Q/R:

Original: Andrews Single Truss Trucks: Kadee #509

Rr-S/T/U/V:

Original: Andrews Class 545: Kadee #509 With Modifications

**10900 Series Operating Era: 1902-1959**

#10900

Original: Arch Bar Trucks: TMW-203 or Kadee #501

Modern, After 1938: Bettendorf: Kadee #500

**11000 Series Operating Era: 1912-1953**

#11000

Pilcher (Lewis) 6 Wheel Trucks: Bethlehem #1241

**11200 Series Operating Era: 1912-1955**

#11200

Life of Cars: Andrews Trucks: TMW-212 or Kadee #509 with Modifications

**11300 Series Operating Era: 1910-1973**

#11300

Original: 5'-0" Wheelbase Arch Bar Trucks: TMW-211 or Bitter Creek #T-20

Soo Line: Early Andrews: TMW-212 or Kadee #509

**11400 Series Operating Era: 1895-1925**

#11400

Original: 5'-0" Wheelbase Arch Bar Truck: TMW-211 or Wiseman #OT-5304

Later: Arch Bar Truck, 50 T: TMW-203 or Kadee #501

**11500 Series Operating Era: 1906-1965**

#11500

Original: Andrews Class 538, Single Truss: Kadee #509 with Modifications

Or

Andrews Class 545 Double Truss: Kadee #509 with Modifications

**11600 Series Operating Era: 1913-1965**

#11600

Original: Arch Bar Trucks: TMW-203 or Kadee #501

Modern, after 1935: Bettendorf: Kadee #500

**11700 Series Operating Era: 1895-1928**

#11700

XG: 5'-0" Wheelbase Arch Bar Truck: TMW-211 or Wiseman #OT-5304

XH: 5'-6" Wheelbase Arch Bar Truck: TMW-203 or Kadee #501

**11800 Series Operating Era: 1915-1959**

#11800

Original: Arch Bar Trucks: TMW-203 or Kadee #501

Or

Bettendorf T Section: Kadee #511

Modern: Andrews Trucks: TMW-212 or Kadee #509

**11900 Series Operating Era: 1890-1927**

#11900

RD/RX: 5'-0" Wheelbase Arch Bar Truck: TMW-211 or Wiseman #OT-5304

RE: 5'-6" Wheelbase Arch Bar Truck: TMW-203 or Kadee #501

**12000 Series Operating Era: 1907-1950**

#12000

Entire Life of Cars: Bettendorf T Section: Kadee #511 (M)

**12100 Series Operating Era: 1944-1971**

#12100

Entire Life of Cars: Barber Lateral Motion: TMW-209

**12200 Series Operating Era: 1916-1960**

#12200

Entire Life of Cars: Class 545, Andrews L Section: Kadee #509 (M)

**12300 Series Operating Era: 1923-1971**

#12300

Entire Life of Cars: Class 551, Andrews U Section: TMW-212

**12400 Series Operating Era:**

#12400